



TAIPAN ECU (T500 OR ALL TYPE) FIRMWARE UPDATE PROCESS


1. OPEN AIM "SPARK" AFTER INSTALLING IT ON YOUR COMPUTER (WINDOWS ONLY)
2. SELECT BY CLICKING THE AIM "CLOUD" TO OPEN THE WINDOW OF UPDATES AVAILABLE FOR DOWNLOAD
3. CHECK THAT THE VERSION CURRENTLY DOWNLOADED ON YOUR PC IS THE SAME AS THE ONE AVAILABLE ONLINE. IF IT IS NOT, IT IS USUALLY INDICATED IN BOLD. SELECT IT AND DOWNLOAD (IN THE FIGURE, YOU ALREADY HAVE THE UPDATED VERSION DOWNLOADED ON YOUR PC)




4. CONNECT YOUR ECU WITH THE UC BRIDGE DEVICE, AND SELECT AT THE TOP > "UPDATES" > "UPDATE ECU FIRMWARE".



5. A WINDOW WILL OPEN TO SELECT THE LATEST UPDATE YOU DOWNLOADED. YOU WILL FIND IT INSIDE C: > AIM SPORT > SPARK > AIM > FIRMWARE > (AND THE RESPECTIVE ECU FOLDER)



6. AFTER A FEW SECONDS OF PROCESS, A SMALL POPUP WILL NOTIFY YOU THAT THE PROCESS IS FINALIZATION AND UPDATE. CLOSE THE WINDOW, DISCONNECT THE ECU AND CLOSE SPARK.



TOMASIN R&D

by GFT S.R.L.

TECH DEPARTMENT

Via dell'Artigianato 2, Orgiano (vi) 36040

Tel. +3904441809121

email info@tomasinracing.com

web www.tomasinracing.com